



# INSTALLATION INSTRUCTIONS

## PUMP OUTLET ADAPTER

UNIVERSAL

Document: 19-0141

Support: info@radiumauto.com

ONLY COMPATIBLE WITH SPECIFIC FUEL PUMPS. CHECK WWW.RADIUMAUTO.COM FOR DETAILS.  
 USE CAUTION WHEN WORKING ON FUEL SYSTEMS. ALWAYS WORK IN A WELL VENTILATED  
 AREA AND CLEAN UP FUEL SPILLS IMMEDIATELY.

STEP	TOOLS NEEDED	INSTRUCTIONS	PHOTO
1		Inspect the pump outlet hose barb. If the hose barb is deformed or damaged, the Radium pump adapter should NOT be used.  An example of a deformed hose barb is shown at right.	
2		Slide the black collar over the pump outlet with the flat surface upward, as shown.	
3		Slip the stainless steel retainer under the hose barb ridge closest to the end of the pump outlet opening, as shown.  <b>NOTE: If purchased prior to March 2020, the retainer will be C-shaped (as shown). If purchased after March 2020, the retainer will be 2-piece half circles.</b>	
4		Place the included O-ring on the pump outlet, as shown.	

5		Slide black collar upward, as shown.	
6	2.5mm Allen Wrench	<p>Apply a high strength thread locking compound to the threads on the 3 included bolts. Line up the upper fitting holes to the black fitting threads. Secure and tighten all bolts evenly.</p> <p>NOTE: 20-0298 is pictured but 20-0599 is very similar.</p> <p><b>Installation complete.</b></p>	
	Thread Locker		