



# INSTALLATION INSTRUCTIONS

## MASTER CYLINDER BRACE

### NISSAN R32 SKYLINE

Document: 19-0260

Support: info@radiumauto.com

STEP	TOOLS NEEDED	INSTRUCTIONS	PHOTO
1		<p>Open the hood. Find the 2 plastic plugs (shown) located on the strut tower just in front of the brake master cylinder. Simply pry the plugs from the threads in the sheet metal. These plugs will NOT be reused.</p> <p>NOTE: it might be necessary to run a M6x1mm tab in each hole to clean the threads.</p>	
2	17mm Wrench	<p>Remove the suspension flange nut underneath the brake master cylinder. This OEM flange nut will NOT be reused.</p>	
3		<p>Install the aluminum bolt and jam nut to the master cylinder brace in the orientation shown. Do NOT secure more than finger tight.</p>	
4		<p>Hang the master cylinder brace to the suspension M12x1.25mm stud on the strut tower.</p>	

5		Install the provided M6x1mm flat head screws to the aforementioned strut tower threads. Do NOT tighten yet.	
6	17mm Wrench 4mm Allen Wrench	Install and tighten the provided M12x1.25mm flange nut to the aforementioned suspension stud on the strut tower.  Next, tighten the two M6x1mm bolts.	
7	13mm Wrench	Spin the aluminum bolt until there is a constant force applied to the brake master cylinder.	
8	13mm Wrench 1/2" Wrench	Tighten the jam nut to prevent the aluminum bolt from vibrating loose.	
9		Installation Complete.	