

# INSTALLATION INSTRUCTIONS

## COOLANT EXPANSION TANK

OEM LOCATION, LOTUS 2ZZ-GE







Document: 19-0132  
Support: info@radiumauto.com







### WARNINGS:


DO NOT WORK ON THE COOLANT SYSTEM WHEN THE ENGINE IS AT OPERATING TEMPERATURE.  
WAIT UNTIL THE ENGINE HAS COOLED AND THERE IS NO LONGER PRESSURE IN THE SYSTEM.

QUICKLY CLEAN UP ANY COOLANT THAT HAS SPILLED AS IT IS POISONOUS.

STEP	TOOLS NEEDED	INSTRUCTIONS	PHOTO
1	3mm Allen wrench	Unwrap the halves of the coolant tank and clean out any residual packaging material.	
	Torque wrench	Place the included gasket in between the 2 coolant tank halves.	
	Anti-seize	Using a 3mm Allen hex wrench, install the 7 included socket head bolts. It is recommended to use anti-seize on the threads to prevent galling.	
		Tighten all bolts evenly until snug in a criss-cross sequence (as shown), then tighten each bolt to 38 in-lbs using a calibrated torque wrench and 3mm hex bit. <b>WARNING: Do not overtighten!</b>	
2		Hand-tighten both elbow fittings in the 1/8" NPT ports. Then add an additional 1.5 to 3 turns until tight. The tapered pipe threads are preimpregnated with Teflon so no addition lubrication is required.	
		In order to install the clear tubing, temporarily clock each fitting, as shown.	
		Verify that the included clear tubing is 81mm (+/-1mm).	
		Push-in and fully insert the tubing into either elbow fitting, as shown.	
3		Bend the tube just enough to get it into the opposing instant tube fitting, as shown. NOTE: the fittings might need to be rotated slightly.	
4	8mm open end wrench	Using an 8mm open end wrench, rotate the elbow fittings so they are in line with one another.	
		NOTE: if not tight enough, the elbow fittings may need to be rotated 360 degrees.	

5		Inspect the tubing. If it is not get completely straight, the tube is most likely slightly too long, as shown.		
		To fix, rotate the elbow fittings back as before. Simultaneously push the retaining locks flush to release the tube from the each elbow fitting.		
		Shorten the tube slightly, then reinstall.		
6		Make sure the area shown in the picture is free of dirt and debris before proceeding.		
		Place the included O-ring into the groove around the fill neck opening.		
7	3mm Allen wrench	Place the included fill neck receiver onto the tank, oriented to best fit the application.		
	Thread locker			
				Apply a medium strength thread locker and install the 3 included socket head bolts using a 3mm Allen hex wrench, as shown. Torque to 48 in-lbs (5.4Nm).
8	Lubrication oil	Before installing the 3 included adapter fittings, lubricate the O-rings with light oil. Secure the two 10AN ORB to 6AN male fittings into the bottom ports and the 6AN ORB to 6AN male fitting to the side port.		
	3/4" wrench			
	1" wrench			NOTE: The tank's internal chambers are divided vertically down the middle for the swirl mechanism, but small passages on the top and bottom allow water to flow throughout the complete tank.
9	Pliers	Before uninstalling, note the functions of the colored hoses shown. <b>Red (14):</b> Hot water air-bleed coming out of the cylinder head. <b>Green (11):</b> Coolant returning from the tank to the thermostat housing. <b>Blue (54):</b> Radiator air-bleed and bypass when thermostat is closed.		
	10mm wrench			These hoses and the <b>overflow tube (46)</b> will be reused. Place a tray and shop towels under the <b>factory coolant tank (15)</b> . Using pliers, slide the <b>spring clamps (41, 42, &amp; 44)</b> down off the coolant tank barb. One by one, gently pull off all 3 hoses. Unscrew the 2 upper <b>M6 bolts (12 &amp; 16)</b> .
10	Cutting dikes	Remove the tank from the vehicle.		
	10mm wrench			Next, the <b>steel bracket assembly (17)</b> will be discarded. Cut the zip ties that are holding the 2 coolant lines in place. Unplug the electric hot soak water pump. Unscrew the <b>M6 bolt (42)</b> , shown at right, that clamps the <b>water pump (18)</b> . Remove the factory <b>M8 bolt (52)</b> near the left side motor mount. This bolt will be reused.
	13mm wrench			
				Carefully lift the steel bracket out without disrupting the water pump that is still attached and plumbed to the engine.

11	13mm wrench	Peel the water pump rubber sleeve off the OEM bracket.	
	17mm wrench	Locate the Radium water pump mount, clamp, M8 bolt, and M8 nut in the kit. Loosely assemble the parts as shown. Rewrap the electric water pump with the OEM rubber sleeve and slide the assembly around the pump.	
		Tighten the included bolts to the two empty M10x1.25 threaded bosses on the transmission case (pictured). Tighten the M8 bolt/nut.	
		Reconnect the electric hot soak water pump.	
12	Thread locker	The mounting bracket will be secured to the coolant tank using the 3 inner slotted bolts holes. Apply a medium strength thread-locker to the three M6 bolts. Secure the bracket to the coolant tank using a 4mm Allen hex wrench.	
	4mm Allen wrench		
	10mm wrench		
	13mm wrench		
13		Gently bend the clamp into an oval D shape so it does not disrupt flow through the 2 large hoses.	
		Push the factory overflow tube onto the Radium neck barbed fitting. It is a bit too big for the barb so use the opposite end. Note: if the engine overheats, coolant will flow out of this port. A long hose (not included) can be attached instead and routed down to the rear of the car.	
14	Hose cutter	Locate the three black 90 degree hose ends in the kit. Before assembling the hose ends to the factory hoses, note how the lines will be routed (pictured). It is necessary to cut the factory "blue" hose shorter to help eliminate a potential air lock.	
		Make sure all 3 hoses flow downwards away from the tank to allow proper air bleeding. Also, be sure to leave enough slack for engine movement.	
15	11/16" wrench	To assemble all 3 included 90 degree hose ends to the factory hoses, simply push the barbed end into each hose, straight hose end shown as example. Make sure the hose is all the way against the hose end nut. Reuse the factory spring clamps to secure the connection, as shown.	
	Pliers		
16	Coolant	Lotus recommends a 50/50 mix of Havoline XLC Extended Life Coolant.	
		When filling the coolant tank, unscrew the rear air bleed plug (pictured). Note: If filling the entire system, there is also an air bleed plug near the radiator and is accessed under the front right removable panel. Opening these bleed screws alleviates a potential air lock.	
		Fill the system slowly until each bleed location spews coolant.	

17	11/16" wrench	Once the tank sight tube registers half full, screw the "red" hose end back into the tank. Note: The level will naturally rise as the engine warms up from heat expansion.	
		Start the engine and monitor the digital coolant display on the dash. Note: There will be no coolant reading until the engine heats up. If the temperature continues to climb towards 212F (100C), there is a trapped air bubble(s). This is common in the 2ZZ-GE. An effective remedy is using a coolant re-filler, such as OTC P/N: 75260 (pictured).	